SPECIFICATIONS

MDS T4 XTR

Power output 4 Ω (watts)	4 x 75 WRMS : 4 x 150 WATT
Power output 2 Ω (watts)	4 x 90 WRMS : 4 x 180 WATT
bridged channel pair(watts)	2 x 150 WRMS : 2 x 300 WATT
THD	≤1%
frequency response (± 1dB)	20Hz-20KHz +/- 1dB
signal to noise ratio	>90dB
sensitivity	
recommended fuse type	25A x2 (13,8V music)
dimensions	260mmX185mmX59mm

STOCKHOLM | SWEDEN
MDS
MAILBOX 2460
111 75 Stockholm
08 556 00 740

OULU | FINLAND
MDS - AUTOVIIHDE
Pauketie 2
90410 Oulu
08 348 300

www.mds.se | www.mds.fi

MDS

HIGH EFFICIENCY POWER AMPLIFIER

OWNER'S MANUAL

CAR AUDIO SYSTEM

PLEASE READ CAREFULLY BEFORE INSTALLING OR OPERATED THIS UNIT

T4

4-Channel Amplifier

The T4 XTR amplifier offers the good balance of power output and compact design required for performance audio systems. The 4-channel configuration allows fine tuning adjustments between front speakers and rear speakers or subwoofer. The built-in crossover allows the front and the rear channels to be configured for running 4-speakers or more.

T4 like all other amplifiers in the T-series are built to be able to sit even in electric cars and at the same time be able to give maximum power (WATT RMS) with considerably less electric power consumption. MDS T-series XTR takes your electric car much longer.

Automated smart Low Amperage Consumption

MDS|HOME PREDATOR DYNAMIC FANATIC XTR

WARNING

Make sure you choose a suitable place to mount the unit. The position should be completely dry with a good circulation of air, and from a mechanical point of view very stable.

www.mds.se | www.mds.fi

System planning

Proper system planning is the best way to maximize your amplifier performance. By planning your installation carefully you can avoid situations where the performance of the reliability of your system is compromised. Your authorized dealer has been trained to maximize your system s sonic potential. Your dealer is a valuable resource in helping you with your system design and installation.

Speaker requirements
Each channel of your amplifier can easily drive 4Ω speaker loads when used in the stereo mode. When a channel-pair is bridged, the recommended minimum load impedance is 3Ω for subwoofer use, and 4Ω for full range operation. Although operation with lower impedances is not likely to cause immediate damage to the internal circuitry, the unit will most likely overheat, causing the thermal protection circuitry to shut down the amplifier. When the chassis cools down, normal operation will resume. Continuing to operate the amplifier under these conditions is not recommended and will reduce its life expectancy.



Series wiring



Parallel wiring

Most speakers designed for car audio operation are 4Ω impedance. Connecting two such speakers in parallel will result in a 2Ω impedance load as seen by the amplifier. Some subwoofer models feature a dual 4Ω voice coil design. Connecting these voice coils in parallel will result in a 2Ω nominal impedance, which is not recommended for use with bridged channels of your amplifier.



Series/parallel wiring

Power Connection Leads



Notes on the power supply

Connect the +12V power input lead only after all other leads have been connected.
Be sure to connect the ground wire of the unit securely to a metal part of the car.
A lose connection may cause a malfunction of the amplifier.
REMOTE: The unit is turned on by applying +12Volts to this terminal This terminal dose not draw heavy current like the two power terminal so a thinner connecting wire is acceptable. Standard 18 GAUGE is fine and the standard colour is yellow. If the radio is equipped with a power antenna control wire, it can drive this terminal. If the power antenna wire is already in use, you can still splice into it. With this method, the unit will turn on automatically with the radio. Use the power supply lead with a fuse attached whose value is the same as original fuse.
Place the fuse in the power supply lead as close as possible to the car battery.
During a full power operation, Maximum current will run through the system. Therefore, Make sure the that the leads to be connected to the +12v and GND terminals of the unit respectively must be larger than 10-Gauge (AWG.10).

system 1: 4 channel mode





system 2: 3 channel mode





system 3: 2channel bridged connection





Troubleshooting

symptom	possible cause	action to take
no output	low or no remote turn-on input	check remote turn-on voltage output at amplifier and correct as needed
	fuse blown	check power wire integrity and reversed polarity ,repair as needed and replace fuse
	power wires not connected	check power wire and ground connections and repair of replace as needed
	audio input not connected or no output from source	check input connections and signal integrity , repair or replace as needed
	speaker wires not connected	check speaker wires and repair or replace as needed
	speakers are blown	check system with known working speaker and repair or replace speakers as needed
audio cycles on and off	thermal protection engages when amplifier heatsink temperature exceeds 90°C	make sure there is proper ventilation for amplifier and improve ventilation as needed
	loose or poor audio input	check input connections and repair or replace as needed
distorted output	amplifier level sensitivity set too high; exceeding maximum output capability of amplifier	reset gain referring to the tuning section of the manual for detailed instructions
	impedance load to amplifier too low	check speaker impedance load if below 2Ω stereo or 4Ω
		mono rewire speakers to achieve a higher impedance
	shorted speaker wires	check speaker wire connections and repair or replace as needed
	speaker not connected to amplifier properly	check speaker wiring and repair of replace as needed refer to the installation section of this manual for detailed instructions

Symptom	possible cause	action to take
	internal crossover not set properly for speaker	reset crossovers referring to the multi-cross crossover configuration section of this manual
distorted output (cont'd)	speakers are blown	check system with known working speakers and repair or replace as needed